



GamerModz.com - 4508 Oak Fair Blvd. - Suite #109 - Tampa, FL 33610 - 1-866-205-5268

GamerModz® 10 Speed Adjustable Rapid Fire

Instructions & Troubleshooting

How to use:

- Turn the controller on and the 4th LED will flash rapidly. (refer to troubleshooting if it does not)
- To change modes, press the sync button the amount of times that corresponds to the mode number. Example: Press the sync button 3 times for mode 3, 5 times for mode 5, etc.
- Once you have set the mode you want to be in, pull the right trigger and it will jump to that mode.
- To turn off the rapid fire, go to mode 11 (or higher) then pull the trigger and Rapid Fire will be off.

Troubleshooting:

If you find your mod not working properly, follow these steps.

- Remove the battery pack for the controller.
- While the battery pack is removed, hold the sync button down.
- While holding the sync button, re-insert the battery pack and turn the controller on IMMEDIATELY!
- Keep holding the sync button until the 4th LED starts flashing rapidly.
- Once it stops flashing, you can release the sync button and you are ready to go!